

Cut-out Template for Kramer T-IN2-RND(1+2)

- To prepare the template make sure you have the following items on hand -
 - Scissors / Pin or pointed tool
 - Ruler
 - Marker
 - Hole Saw 140 mm / 5.5"
- **Pre-requisites** -
 - Confirm the product to be installed
 - Verify all dimensions to ensure that this print is 1:1 scale

1. Preparing the cut-out - Pierce the center of the circle to mark a hole in the surface
2. Mark the position on the furniture using the marker
3. Double check dimensions and position
4. Cut-out the opening

**PRINT SCALE 1:1
DO NOT SHRINK OR ADJUST!**

CONFIRM USING A RULER

